



Quantitative Inspection of Complex Composite Aeronautic Parts Using Advanced X-ray Techniques

Aerodays 2015

London / UK, 21.10.2015


Christoph Heinzl



University of Applied Sciences

**Rising
Demands on
Components**

- Cost effectiveness
- Function orientation
- High integration
- Light weight




**Advanced
Composites**

- Most promising candidate materials
- Integrate demands for the aircraft of the future

Mission statement: “...to take the next big step in quality control and development of new advanced composite components for the aircraft of the future...”

Hardware | Software | Simulation

- Consists of **3 Pillars**:
- In order to ...




Hardware | Software | Simulation


- **Robot based XCT** for large and complex aeronautic parts at production site
- **Fast process integrated XCT** for fast and reliable inspection of small high volume parts
- **X-ray radiography, tomosynthesis and Computed tomography**




- **Computed Tomography** with cooperating industrial robots as manipulators for X-ray source and detector
- **Extreme flexibility** to acquire CT at large or inaccessible objects



- **Solution for unknown geometry**
(industrial robots are only precise for approx. 0.5 mm to 1 mm)
- Computed tomography with details **down to few tens of microns**




Aerodays 2015, London / UK, 21.10.2015



Christoph Heinzl

- Process integrated XCT of **thermoplast clips** (typically 100 mm · 150 mm · 200 mm)
- **Multi-Clip scan** with automatic separation of individual clips
- **Automatic dissection** in planes and radii
- **High resolution** to detect porosity and delaminations
- **½ to 5 minutes per clip** for scan and **automatic defect recognition**




Characterization of **light-weight, fiber reinforced plastic composites combined with metallic parts.**

Composites with **metallic inlays**


Sandwich structures with **metal core**

Metal fasteners



Dual Energy CT (DECT)

Resultant reconstruction obtained combining two CT measurements at two different X-ray spectra.



Disbonding of two glued parts


3 basic material components:

- **CFRP** (two 1.2 mm thick flat parts, each from 6 layers),
- **metal fastener** (steel rivet Avinox II) and
- **Cu grid** (4AE420539).


Artificial disbonding between glued CFRP parts was prepared in the rivet vicinity




LE @80kV,
1.5 mm Al filter
CT reconstruction



HE @160kV,
0.8 mm Sn filter
CT reconstruction






DECT reconstruction







Hardware | **Software** | Simulation

- **Material characterization** regarding fibers, fiber bundles, pores, voids etc.
- **Data analysis and interpretation of results**
- **Large data analysis and visualization**
- **Hardware accelerated methods and techniques**




(images courtesy of VG, FHW)






- A. **3D Renderer:** fiber/pore visualization in the volume
- B. **Scatterplot Matrix:** detailed fiber/pore selection according to their characteristics
- C. **Polar Plot:** overview of fiber frequency distribution in volume
- D. **Parallel Coordinates:** coarse fiber/pore selection according to their characteristics
- E. **Class and Element Explorer:** fiber/pore class definition, browsing and statistics of fiber characteristics



Original CT data




MetaTracts data



Hardware | Software | **Simulation**


- **X-ray simulation**
Dedicated simulations for each of proposed part type for optimal XCT scans
- **CFRP modeling and simulation**
based on XCT data including flaws
characterize precise mechanical properties



(images courtesy of UPAT)


- **Advantages**

- Geometrically simple – no need in triangulation / meshing of complex domains
- Free from the problem of yarns interpenetration
- Derivation from 3D CT images provides a way to model the material structure exactly as it is
 - hence no idealization




- **Applications**

- Meso-level homogenization
- Virtual testing for damage development
- Preform permeability calculation



Multi-level Modeling of Porous CFRPs



- **Basic features**


- Models derived from Defect Analysis of CT images-Accuracy, Robust information
- Distinguished impact of the effect of small and larger pores
- Parametric RVEs regarding the Porosity Volume Fraction ($V_f\%$), Pore size and Population
→ Adaptive to every porosity case
- The progression of damage is simulated through the Progressive Damage Model at the Macro scale

- **Main results**

- Mechanical properties of the matrix in the presence of small and large pores
- Mechanical properties of the CFRP laminate

Sneak peek into the **3 pillars** of the **QUICOM Technology platform**

- Hardware
 - **RobotCT**
 - **Fast process integrated CT**
- Software
 - **Comparison of CT with US** data
 - **FiberScout**, a visualization system for visual analysis of fiber, void, pore, crack etc., characteristics in FRPs.
- Simulation
 - **Voxel-based modelling** for textile composites
 - **Multi-level Modeling** of Porous CFRPs





This document and all information contained herein is the sole property of the QUICOM Consortium or the company referred to in the slides. It may contain information subject to intellectual property rights. No intellectual property rights are granted by the delivery of this document or the disclosure of its content.

Reproduction or circulation of this document to any third party is prohibited without the consent of the author(s).

The statements made herein do not necessarily have the consent or agreement of the QUICOM consortium and represent the opinion and findings of the author(s).

All rights reserved.

The logo for the European Aeronautics Science Network (EASN), featuring a stylized blue and yellow graphic of a network or structure.

The project is endorsed by the European Aeronautics Science Network – EASN.

Thanks for your attention!

Questions?

